



TÄYDELLISTÄ HITSAUSTA

# **ROBACTA TX W**

/ Operating Instructions  
/ Spare Parts List

# Dear reader,

---

## **Introduction**

Thank you for the trust you have placed in our company and congratulations on buying this high-quality Fronius product. These instructions will help you familiarise yourself with the product. Reading the instructions carefully will enable you to learn about the many different features it has to offer. This will allow you to make full use of its advantages.

Please also note the safety rules to ensure greater safety when using the product. Careful handling of the product will repay you with years of safe and reliable operation. These are essential prerequisites for excellent results.



# Contents

Safety rules.....	7
Explanation of safety symbols .....	7
General .....	7
Proper use .....	8
Environmental conditions.....	8
Obligations of the operator.....	8
Obligations of personnel .....	9
Specific hazards.....	9
Protecting yourself and others .....	9
EMC device classifications .....	9
EMC measures .....	10
EMF measures.....	10
Safety measures at the installation location.....	10
Safety measures in normal operation .....	11
Maintenance and repair .....	11
Safety inspections.....	11
Disposal .....	11
Safety symbols.....	12
Data protection.....	12
Copyright.....	12
<b>General information</b> .....	<b>13</b>
General .....	15
Device concept .....	15
Scope of supply .....	15
System components .....	16
Necessary system components.....	16
Contact tip recommendation .....	17
Note on wirefeeding.....	17
Compatible system components for the overall welding system .....	17
TCP measurement system .....	18
Warning notices on the device.....	19
Warning notices on the device.....	19
Transport.....	21
Transport devices .....	21
Transport notices on the packaging.....	21
<b>Controls, connections and mechanical components</b> .....	<b>23</b>
Control elements and connections.....	25
Control elements and connections.....	25
Mechanical components .....	26
Mechanical components .....	26
Pin assignments and signal descriptions .....	27
Safety.....	27
Assignment of standard I/O connection for robot control.....	27
Assignment of connection to external power supply.....	28
Signal descriptions.....	29
<b>Installation and commissioning</b> .....	<b>33</b>
Safety.....	35
Safety.....	35
Before installation and commissioning.....	36
Proper use .....	36
Operators, maintenance personnel.....	36
Setup regulations .....	36
Specifications for water-cooled hosepacks.....	36
Compressed air supply requirements .....	37



Compressed air supply specifications.....	37
Application example.....	38
Application example.....	38
Bolt torch neck changeover station to the underlying surface (foundation) .....	39
Safety.....	39
Bolt torch neck changeover station to the underlying surface (foundation) .....	39
Installing the torch neck changeover station - in conjunction with VR 7000 / VR 7000 CMT .....	40
Safety.....	40
General .....	40
Preparation .....	40
Installing the torch neck changeover station.....	42
Installing the torch neck changeover station - in conjunction with VR 1500 / VR 1530 / VR 1550 .....	43
Safety.....	43
General .....	43
Preparation .....	43
Installing the torch neck changeover station.....	44
Installing the torch neck changeover station - in conjunction with VR 1500-PAP .....	45
Safety.....	45
General .....	45
Preparation .....	45
Installing the torch neck changeover station.....	47
Checking the torch neck sensor, setting the wire sensor.....	48
Safety.....	48
Checking the torch neck sensor.....	48
Setting the wire sensor .....	49
Preparing torch neck with steel inner liner .....	50
Preparing the torch neck.....	50
Preparing the torch neck with plastic inner liner .....	52
Preparing the torch neck.....	52
Preparing system components for Robacta hosepacks.....	54
Safety.....	54
Preparing the torch neck coupling for Robacta hosepacks.....	54
Preparing the inner liner for Robacta hosepacks.....	55
Preparing the torch neck coupling for Robacta Drive and Robacta Drive CMT hosepacks with steel inner liners .....	57
Preparing the torch neck coupling for Robacta Drive and Robacta Drive CMT hosepacks.....	57
Preparing the torch neck coupling for Robacta Drive and Robacta Drive CMT hosepacks with plastic inner liners .....	58
Preparing the torch neck coupling for Robacta Drive and Robacta Drive CMT hosepacks.....	58
Preparing the power source.....	59
Preparing the power source.....	59
Fitting the torch neck coupling .....	60
Safety.....	60
Fitting the torch neck coupling .....	60
Configuring torch neck for special rack positions.....	61
General .....	61
Turning the torch neck insulation .....	61
Connecting and adjusting the compressed air amplifier .....	62
General .....	62
Connecting the compressed air amplifier.....	62
Adjusting the compressed air amplifier .....	63
And finally... ..	63
Changing the torch neck manually.....	64
Safety.....	64
Changing the torch neck manually.....	64
Setting up the robot.....	66
Dimensions of the rack holder including torch neck racks .....	66
Safety.....	66
Determining the TCP of the welding torch, determining the X-axis and Y-axis of the torch neck change-over station .....	67
Fitting the robot programming aid .....	67
Setting up the robot.....	69
Start-up .....	71
Prerequisites for start-up.....	71

Start-up .....	71
<b>Program sequence</b> .....	<b>73</b>
Program sequence .....	75
Speed data for the program sequence .....	75
Subprograms in the program sequence .....	75
Program sequence .....	76
<b>Troubleshooting</b> .....	<b>83</b>
Safety .....	85
Safety .....	85
Troubleshooting .....	86
Troubleshooting .....	86
<b>Care, maintenance and disposal</b> .....	<b>89</b>
Safety .....	91
Safety .....	91
Maintenance for each torch neck service, at least weekly .....	92
Preparation .....	92
Safety .....	92
Checking the torch neck for damage and wear .....	93
Checking the torch neck coupling .....	94
Changing the steel inner liner in the torch neck .....	94
Changing the plastic inner liner in the torch neck .....	97
And finally... ..	99
Monthly maintenance - changing the inner liner in the centre bolt .....	100
Preparation .....	100
Safety .....	100
Changing the steel inner liners for Robacta Drive and Robacta Drive CMT hosepacks .....	101
Changing the plastic inner liners for Robacta Drive and Robacta Drive CMT hosepacks .....	102
And finally... ..	103
Maintenance when required .....	104
Maintenance when required .....	104
Servicing the centre bolt .....	105
Preparation .....	105
Safety .....	105
Centre bolt .....	106
And finally... ..	107
Changing coolant stops .....	108
Preparation .....	108
Safety .....	108
Removing coolant stops .....	109
Preparing new coolant stops .....	109
Fitting new coolant stops .....	111
And finally... ..	111
Cleaning the gas hole .....	112
Preparation .....	112
Safety .....	112
Cleaning the gas hole .....	113
And finally... ..	114
Pressing the emergency release button .....	115
General .....	115
Preparation .....	115
Safety .....	115
Pressing the emergency release button .....	116
Replacing the torch neck sensor .....	117
Preparation .....	117
Safety .....	117
Removing the old torch neck sensor .....	117
Fitting the new torch neck sensor .....	118
And finally... ..	119

Disposal .....	120
Disposal .....	120
<b>Technical data</b>	<b>121</b>
Technical data .....	123
Torch neck changeover station .....	123
Torch neck coupling .....	123
<b>Appendix</b>	<b>125</b>
Circuit diagram: Robacta TX W .....	126
Circuit diagram: Accessory equipment .....	127
Circuit diagram: Device communication .....	128
Pneumatic diagram .....	129
Declaration of installation .....	130

# Safety rules

## Explanation of safety symbols



**DANGER!** indicates immediate and real danger. If it is not avoided, death or serious injury will result.



**WARNING!** indicates a potentially dangerous situation. Death or serious injury may result if appropriate precautions are not taken.



**CAUTION!** indicates a situation where damage or injury could occur. If it is not avoided, minor injury and/or damage to property may result.



**NOTE!** indicates a risk of flawed results and possible damage to the equipment.

**IMPORTANT!** indicates tips for correct operation and other particularly useful information. It does not indicate a potentially damaging or dangerous situation.

If you see any of the symbols depicted in the "Safety rules", special care is required.

## General



The device is manufactured using state-of-the-art technology and according to recognised safety standards. If used incorrectly or misused, however, it can cause

- injury or death to the operator or a third party,
- damage to the device and other material assets belonging to the operating company,
- inefficient operation of the device.

All persons involved in commissioning, operating, maintaining and servicing the device must:

- be suitably qualified,
- have sufficient knowledge of welding
- read and follow these operating instructions carefully.

The operating instructions must always be at hand wherever the device is being used. In addition to the operating instructions, attention must also be paid to any generally applicable and local regulations regarding accident prevention and environmental protection.

All safety and danger notices on the device

- must be kept in a legible state
- must not be damaged/marked
- must not be removed
- must not be covered, pasted or painted over.

For the location of the safety and danger notices on the device, refer to the section headed "General remarks" in the operating instructions for the device. Before switching on the device, remove any faults that could compromise safety.

**Your personal safety is at stake!**

---

## Proper use



The device is to be used exclusively for its intended purpose.

The device is intended solely for the welding processes specified on the rating plate.

Any use above and beyond this purpose is deemed improper. The manufacturer shall not be held liable for any damage arising from such usage.

Proper use also includes:

- carefully reading and following all the instructions given in the operating instructions
- studying and obeying all safety and danger notices carefully
- carrying out all the specified inspection and servicing work.

The device is designed for use in industry and the workshop. The manufacturer accepts no responsibility for any damage caused through use in a domestic setting.

The manufacturer likewise accepts no liability for unexpected or incorrect results.

---

## Environmental conditions



Operation or storage of the device outside the stipulated area will be deemed as "not in accordance with the intended purpose". The manufacturer shall not be liable for any damage resulting from such improper use.

Ambient temperature:

- during operation: 0 °C to + 40 °C (32 °F to 104 °F)
- during transport and storage: -25 °C to +55 °C (-13 °F to 131 °F)

Relative humidity:

- up to 50 % at 40 °C (104 °F)
- up to 90 % at 20 °C (68 °F)

Ambient air: free from dust, acids, corrosive gases and substances, etc.

For use at altitudes above sea level: up to 2000 m (6500 ft)

---

## Obligations of the operator




The operator undertakes only to allow persons to work with the device who:

- are familiar with the fundamental instructions regarding safety and accident prevention, and have been instructed how to use the device
- have read and understood these operating instructions, especially the section "safety rules", and have confirmed as much with their signatures
- are trained to produce the required results.

Checks must be carried out at regular intervals to ensure that operators are working in a safety-conscious manner.

**Obligations of personnel**



- Before using the device, all persons instructed to do so undertake:
- to observe the basic instructions regarding safety at work and accident prevention
  - to read these operating instructions, especially the "Safety rules" section and sign to confirm that they have understood them and will follow them.

Before leaving the work area, ensure that people or property cannot come to any harm in your absence.

**Specific hazards**



Stay out of the working area of the robot.

The device must be incorporated into a higher-level safety system within a secured area.

If this area has to be accessed when setup and maintenance work is carried out, make sure that

- the entire system is switched off for the duration of the work in this area
- and that it is prevented from starting up accidentally, e.g. as the result of a control fault

In addition to these operating instructions, the robot manufacturer's operating instructions and safety rules must also be observed.

**Protecting yourself and others**



When welding, you expose yourself to numerous dangers. In addition to these operating instructions, the safety rules of the manufacturer of the entire welding system must also be observed.

Keep all persons, especially children, out of the working area while any devices are in operation or welding is in progress. If, however, there are people in the vicinity,

- make them aware of all the dangers and health risks (crushing, injury from cutters and sparks, dazzling by arc, inhaling welding fumes, noise, possible danger from mains or welding current, etc),
- provide suitable protective equipment or
- erect suitable safety screens/curtains.

**EMC device classifications**



Devices with emission class A:

- are only designed for use in an industrial setting
- can cause conducted and emitted interference in other areas.

Devices with emission class B:

- satisfy the emissions criteria for residential and industrial areas. This also applies to residential areas in which power is supplied from the public low-voltage grid.

EMC device classification according to the rating plate or the technical data.

---

## EMC measures



In certain cases, even though a device complies with the standard limit values for emissions, it may affect the application area for which it was designed (e.g. when there is sensitive equipment at the same location, or if the site where the device is installed is close to either radio or television receivers).

If this is the case, then the operating company is obliged to take appropriate action to rectify the situation.

Check for possible problems, and check and evaluate neighbouring devices' resistance to interference according to national and international requirements:

- Safety features
- power, signal and data transfer lines
- IT and telecommunications devices
- measuring and calibrating devices

Supporting measures for avoidance of EMC problems:

- a) Mains supply
  - If electromagnetic interference arises despite correct mains connection, additional measures are necessary (e.g. use of a suitable line filter).
- b) Control lines
  - must be kept as short as possible
  - must run close together (to avoid EMF problems)
  - must be kept well apart from other leads
- c) Equipotential bonding
- d) Shielding, if necessary
  - shield off other nearby devices
  - shield off entire welding installation

---

## EMF measures




Electromagnetic fields may pose as yet unknown risks to health:

- effects on the health of others in the vicinity, e.g. wearers of pacemakers and hearing aids
- wearers of pacemakers must seek advice from their doctor before approaching the device or any welding that is in progress
- for safety reasons, keep distances between the welding cables and the welder's head/torso as large as possible
- do not carry welding cables and hosepacks over the shoulders or wind them around any part of the body

---

## Safety measures at the installation location



A device that topples over can easily kill someone. Place the device horizontally on a level, firm and solid surface and anchor it securely to prevent it toppling over.



Special regulations apply in rooms at risk of fire or explosion

- observe relevant national and international regulations.

Use internal directives and checks to ensure that the workplace environment is always clean and tidy.

**Safety measures in normal operation**



Only operate the device when all protection devices are fully functional. If the protection devices are not fully functional, there is a risk of

- injury or death to the operator or a third party,
- damage to the device and other material assets belonging to the operator,
- inefficient operation of the device.

Any safety devices that are not functioning properly must be repaired before switching on the device.

Never bypass or disable protective equipment.

Before switching on the device, ensure that no one is likely to be endangered.

Check the device at least once a week for obvious damage and proper functioning of safety devices.

**Maintenance and repair**



It is impossible to guarantee that bought-in parts are designed and manufactured to meet the demands made on them, or that they satisfy safety requirements. Use only original replacement and wearing parts (also applies to standard parts).

Do not carry out any modifications, alterations, etc. to the device without the manufacturer's consent.

Components that are not in perfect condition must be changed immediately. When ordering, please give the exact designation and part number as shown in the spare parts list, as well as the serial number of your device.

**Safety inspections**



The manufacturer recommends that a safety inspection of the device is performed at least once every 12 months.

A safety inspection should be carried out by a qualified electrician

- after any changes are made
- after any additional parts are installed, or after any conversions
- after repair, care and maintenance has been carried out
- at least every twelve months.

For safety inspections, follow the appropriate national and international standards and directives.

Further details on safety inspection and calibration can be obtained from your service centre. They will provide you on request with any documents you may require.

**Disposal**



Do not dispose of this device with normal domestic waste! To comply with the European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation as national law, electrical equipment that has reached the end of its life must be collected separately and returned to an approved recycling facility. Any device that you no longer require must either be returned to your dealer or given to one of the approved collection and recycling facilities in your area. Ignoring this European Directive may have potentially adverse affects on the environment and your health!




---

**Safety symbols**

Devices with the CSA test mark satisfy the requirements of the relevant standards in Canada and the USA.

---

**Data protection**

The user is responsible for the safekeeping of any changes made to the factory settings. The manufacturer accepts no liability for any deleted personal settings.

---

**Copyright**


Copyright of these operating instructions remains with the manufacturer.

The text and illustrations are all technically correct at the time of printing. We reserve the right to make changes. The contents of the operating instructions shall not provide the basis for any claims whatsoever on the part of the purchaser. If you have any suggestions for improvement, or can point out any mistakes that you have found in the instructions, we will be most grateful for your comments.

# **General information**



## Device concept




Robacta TX is an automatic torch neck changeover system, comprising:

- Torch neck changeover station
- Torch neck coupling
- Robacta TX torch neck


With Robacta TX, robots are used to automatically place worn torch necks onto the torch neck changeover station and replace them with new torch necks. Even switching between different torch neck geometries is easy with Robacta TX.

In conjunction with a welding torch cleaning device, Robacta TX is converted into a fully autonomous torch neck maintenance station that increases system availability and significantly reduces setup time.

## Scope of supply



- (1) Torch neck changeover station with 3 torch neck racks
- (2) 4 adjustment plates 1 mm (0.04 inch)
- (3) 4 adjustment plates 1.5 mm (0.06 inch)
- (4) Operating instructions (not shown)




- (5) Junction valve
- (6) Compressed air line, outer diameter 6 mm
- (7) Compressed air line, outer diameter 8 mm
- (8) 2x M5 self-locking hexagon nuts
- (9) Fitting panel
- (10) 2x A5 washers
- (11) 2x TX25 screws
- (12) 2x M5 x 30 mm Allen screws
- (13) Compressed air connection, diameter 8 mm

# System components

## Necessary system components

To operate the torch neck changeover station, the following system components are also needed in addition to the welding system:


- Robacta TX W torch neck changeover station
- TX W tool kit
- Torch neck coupling
- Robacta TX W torch neck
- Wire cutter
- Compressed air maintenance unit with filter
- Robot



Torch neck changeover station

The torch neck changeover station is used to:


- hold up to 10 torch necks
- hold a welding torch cleaning device
- hold a wire cutter
- hold a TCP measurement system



TX W tool kit


TX W tool kit, comprising

- (1) Installation tool for torch neck coupling
- (2) Assembly aid for torch neck insulation
- (3) Robot programming aid (2 parts)
- (4) 3 TCP tips
- (5) Bit insert for coolant stop
- (6) Cutting aid




Torch neck coupling

- The torch neck coupling enables the torch neck to be changed, length of coupling = 50 mm (1.97 in.)
- NOTE!** The locking balls (1) are intended for dry operation. Do not lubricate the locking balls.



Robacta TX W torch neck



Wire cutter

**Contact tip recommendation**



**NOTE!** In conjunction with the torch neck changeover system, we recommend that you use the 'CB' contact tip.

**Note on wirefeeding**



**NOTE!** The torch neck changeover system can only be used in conjunction with wirefeeding from the drum coil.

**Compatible system components for the overall welding system**

Only use the torch neck changeover system in conjunction with the following system components:

- Any power source from the TS/TPS series
- Any Fronius robot wire-feed unit
- Robacta hosepacks
- Robacta Drive hosepacks
- Robacta Drive CMT hosepacks
- Robacta Reamer V Easy, Robacta Reamer V
- Robacta Reamer aluminium brush head
- Robacta TC series

---


**TCP measurement system**

Use a TCP measurement system in order to achieve the best possible accuracy from the welding system and torch neck changeover system.

# Warning notices on the device

## Warning notices on the device

The device has safety symbols on the rating plate. The safety symbols must not be removed or painted over. The symbols warn against operating the equipment incorrectly, as this may result in serious injury and damage.



**WARNING!** Risk of severe injury from mechanically powered parts. Keep device free from current and pressure during maintenance and servicing.



Do not use the functions described here until you have thoroughly read and understood the following documents:

- these operating instructions
- all the operating instructions for the system components, especially the safety rules





For indoor use only

---



**WARNING!** Risk of severe injury from falling torch necks. Pressing the Unlock/Lock button will release the torch neck from the torch neck coupling, causing it to fall to the ground. When pressing the Unlock/Lock button, make sure that

- the torch neck can be caught with one hand or is safely deposited in a torch neck rack on the torch neck changeover station
  - there are no other persons in the working area of the robot
-

# Transport

---

## Transport devices

The device is to be transported by the following devices:

- on pallets using a forklift truck
- on pallets using a lift truck



**WARNING!** Equipment that falls or topples over can cause serious or even fatal injury.

- Secure the device to prevent it from falling over when transporting on a forklift truck or lift truck
- Do not suddenly change direction, brake or accelerate

---

## Transport notices on the packaging



**CAUTION!** Risk of damage due to incorrect transport. Observe the transport notices on the device packaging.




# **Controls, connections and mechanical components**



# Control elements and connections

## Control elements and connections




No.	Function
(1)	<b>Wire sensor</b> checks whether the wire electrode is protruding from the welding torch
(2)	<b>I/O connection for accessory equipment</b> supplied with 24 V DC
(3)	<b>Compressed air connection "C"</b>
(4)	<b>Unlock/Lock button</b> for manual operation of the torch neck coupling
<p><b>! WARNING!</b> Risk of severe injury from falling torch necks. Pressing the Unlock/Lock button will release the torch neck from the torch neck coupling, causing it to fall to the ground. When pressing the Unlock/Lock button, make sure that</p> <ul style="list-style-type: none"> <li>- the torch neck can be caught with one hand or is safely deposited in a torch neck rack on the torch neck changeover station</li> <li>- there are no other persons in the working area of the robot</li> </ul>	
(5)	<b>Compressed air connection "A"</b> to supply the torch neck coupling with compressed air
(6)	<b>External power supply connection "A"</b> supplied with 24 V DC
(7)	<b>Robot control connection compartment</b> for optionally connecting the torch neck changeover station to the robot control via <ul style="list-style-type: none"> <li>- standard I/O connection for robot control</li> <li>- field bus coupler</li> </ul>
(8)	<b>Compressed air connection "B"</b> connection to supply the torch neck changeover station with 5.50 - 6.00 bar (79.77 - 87.02 psi) of dry and oil-free compressed air <ul style="list-style-type: none"> <li>- Size: 3/8" (0.375 in.)</li> </ul>
(9)	<b>External power supply connection "B", optional only</b> supplied with 24 V DC



# Mechanical components

---

## Mechanical components



---

No.	Function
-----	----------

---

(1)	<b>Rack holder</b> for holding the torch neck racks
-----	--

---

(2)	<b>Mounting bracket</b> for attaching accessory equipment
-----	--




---

(3)	<b>Torch neck rack</b> for holding a torch neck
-----	--



---


# Pin assignments and signal descriptions

## Safety

-  **WARNING!** Machines that start up automatically can cause serious injury and damage. In addition to these operating instructions, the safety rules issued by the manufacturers of the robot and welding systems must also be observed. For your personal safety, ensure that all protective measures have been taken and will remain in place for the duration of your stay within the working area of the robot.
-  **WARNING!** Risk of severe injury from mechanically powered parts. The device must remain depressurised and de-energised until installation has been completed.
-  **WARNING!** Machines that start up automatically can cause serious injury and damage. The device may only be powered through an Emergency Stop circuit.


## Assignment of standard I/O connection for robot control

-  **CAUTION!** Risk of damage to connection supply due to overcurrent. Secure supply against overcurrent with a 1.5 A slow-blow fuse.
-  **NOTE!** To avoid faults, keep the cable between the torch neck changeover station and the robot control as short as possible.





Pin	Input (from the torch neck changeover station to the robot)	Output (from the robot to the torch neck changeover station)	Signal
1		X	+ 24 V
2		X	GND
3	X		Torch neck sensor 1
4	X		Torch neck sensor 2
5	X		Torch neck sensor 3
6	X		Torch neck sensor 4
7	X		Torch neck sensor 5
8	X		Torch neck sensor 6




Pin	Input (from the torch neck changeover station to the robot)	Output (from the robot to the torch neck changeover station)	Signal
9	X		Torch neck sensor 7
10	X		Torch neck sensor 8
11	X		Torch neck sensor 9
12	X		Torch neck sensor 10
13	X		Robacta TX sensor 1 cover
14	X		Robacta TX sensor 2 cover
15		X	Robacta TX valve 1 cover
16		X	Robacta TX valve 2 cover
17	X		'C-Act. 3' signal 1
18	X		Robacta TX chute sensor
19	X		Wire sensor signal
20	X		'C-Sens. 4' signal 2
21	X		'C-Sens. 4' signal 1
22	X		Pressure switch signal
23		X	 <b>NOTE!</b> Switch the valve via a relay, as the current input of the valve is at least 500 mA.  Change torch neck valve 1
24		X	Reserve relay OUT
25	X		'C-Sens. 5' signal 2
26		X	Clamp gas nozzle / motor on / start cleaning
27	X		Gas nozzle free / 'TC Ready'
28	X		Gas nozzle clamped / motor lowered
29	X		Motor turning
30		X	Spray in parting agent
31	X		Fill level of parting agent
32		X	Lifting device up
33	X		Lifting device lowered / 'Cleaning Error'
34	X		Lifting device raised
35		X	Wire cutter
36	X		Wire cutter closed
37	X		Wire cutter open

**Assignment of connection to external power supply**

 **CAUTION!** Risk of damage to connection supply due to overcurrent. Secure supply against overcurrent with a 1.5 A slow-blow fuse.


 **NOTE!** To avoid faults, keep the cable between the torch neck changeover station and the robot control as short as possible.



1	+ 24 V
2	GND
3	-
4	-
5	-

### Signal descriptions

Pin	Signal designation	Signal description
3	Torch neck sensor 1	The respective torch neck is deposited in the corresponding torch neck rack
4	Torch neck sensor 2	
5	Torch neck sensor 3	
6	Torch neck sensor 4	
7	Torch neck sensor 5	
8	Torch neck sensor 6	
9	Torch neck sensor 7	
10	Torch neck sensor 8	
11	Torch neck sensor 9	
12	Torch neck sensor 10	
13	Robacta TX sensor 1 cover	Signal only available as an option. - Robacta TX cover 1 is open
14	Robacta TX sensor 2 cover	Signal only available as an option. - Robacta TX cover 2 is open
15	Robacta TX valve 1 cover	Signal only available as an option. - opens and closes a Robacta TX cover
16	Robacta TX valve 2 cover	Signal only available as an option. - opens and closes a Robacta TX cover
17	'C-Act. 3' signal 1	Reserve signal for actuator
18	Robacta TX chute sensor	Signal only available as an option. - torch neck has been deposited in the Robacta TX chute
19	Wire sensor signal	Verification whether the wire electrode protrudes from the torch neck after a successful change of the torch neck.
20	'C-Sens. 4' signal 2	Reserve signal for sensor
21	'C-Sens. 4' signal 1	Reserve signal for sensor
22	Pressure switch signal	Compressed air supply to torch neck change-over station is OK. The signal is output in a range of 12.5 - 13 bar.

Pin	Signal designation	Signal description
23	Change torch neck valve 1	 <b>NOTE!</b> Switch the valve via a relay, as the current input of the valve is at least 500 mA.  Activates the torch neck change
24	Reserve relay OUT	Reserve signal for actuator (relay contact)
25	'C-Sens. 5' signal 1	Reserve signal for sensor
26	Clamp gas nozzle / motor on / start cleaning	<p>Signal only available as an option.</p> <p>Activates the gas nozzle clamping device, the motor cleaning cutter/brush head, the cleaning process (Robacta TC devices)</p>
27	Gas nozzle free / 'TC Ready'	<p>Signal only available as an option.</p> <p>"Gas nozzle free" signal for Robacta Reamer V only:</p> <ul style="list-style-type: none"> <li>- gas nozzle clamping device on welding torch cleaning device is not holding a gas nozzle</li> </ul> <p>'TC Ready' signal for Robacta TC devices only:</p> <ul style="list-style-type: none"> <li>- welding torch cleaning device is ready</li> </ul>
28	Gas nozzle clamped / motor lowered	<p>Signal only available as an option.</p> <p>"Gas nozzle clamped" signal for Robacta Reamer devices only (except for Robacta Reamer aluminium brush head):</p> <ul style="list-style-type: none"> <li>- a gas nozzle is being held by the gas nozzle clamping device on the welding torch cleaning device</li> </ul> <p>"Motor lowered" signal for Robacta Reamer aluminium brush head only:</p> <ul style="list-style-type: none"> <li>- brush head motor is lowered</li> </ul>
29	Motor turning	<p>Signal only available as an option.</p> <p>"Motor turning" signal for Robacta Reamer V only:</p> <ul style="list-style-type: none"> <li>- cleaning cutter motor turning and emitting constant pulses</li> </ul>
30	Spray in parting agent	<p>Signal only available as an option.</p> <p>"Spray in parting agent" signal for Robacta Reamer V only:</p> <ul style="list-style-type: none"> <li>- activates the spraying in of the parting agent</li> </ul>
31	Fill level of parting agent	<p>Signal only available as an option.</p> <p>"Fill level of parting agent" signal for Robacta Reamer V only:</p> <ul style="list-style-type: none"> <li>- parting agent is in the parting agent container</li> </ul>

<b>Pin</b>	<b>Signal designation</b>	<b>Signal description</b>
32	Lifting device up	Signal only available as an option.  "Lifting device up" signal for Robacta Reamer V only: - activates the upward movement of the lifting device
33	Lifting device lowered / 'Cleaning Error'	Signal only available as an option.  "Lifting device lowered" signal for Robacta Reamer V and Robacta Reamer aluminium brush head only: - gas nozzle cutter motor is lowered / brush head motor is lowered  'Cleaning Error' signal for Robacta TC devices only: - error during cleaning
34	Lifting device raised	Signal only available as an option.  "Lifting device raised" signal for Robacta Reamer V only: - lifting device is raised
35	Wire cutter	Signal only available as an option. - activates the wire cutter
36	Wire cutter closed	Signal only available as an option. - wire cutter is closed
37	Wire cutter open	Signal only available as an option. - wire cutter is open



# **Installation and commissioning**



## Safety



**NOTE!** Observe the following safety instructions for all work described in the "Installation and start-up" section.



**WARNING!** Work that is carried out incorrectly can cause serious injury or damage. The activities described below must only be carried out by trained and qualified personnel. Do not carry out the activities described below until you have fully read and understood the following documents:

- these operating instructions
- all the operating instructions for the system components, especially the safety rules



**WARNING!** Machines that start up automatically can cause serious injury and damage. In addition to these operating instructions, the safety rules issued by the manufacturers of the robot and welding systems must also be observed. For your personal safety, ensure that all protective measures have been taken and will remain in place for the duration of your stay within the working area of the robot.



**WARNING!** Work that is carried out incorrectly can cause serious injury or damage. Before starting work:

- turn the power source mains switch to the "O" position
- disconnect the power source from the mains
- put up an easy-to-understand warning sign to stop anybody inadvertently switching it back on again



**CAUTION!** Risk of injury from sharp flying parts. During the work described below, always wear the following protective equipment:

- Protective goggles with side protection
- Gloves - electrically insulated and providing protection against heat



# Before installation and commissioning

---

## Proper use

The device is intended solely for changing water-cooled Fronius torch necks.

The device is intended solely for use in conjunction with Fronius system components.

Any use above and beyond this purpose is deemed improper. The manufacturer is not liable for any damage, inadequate or incorrect results arising out of such misuse.

Proper use also includes:

- carefully reading and obeying all operating instructions and safety and danger notices
- performing all stipulated inspection and maintenance work

The device is designed for use in industry and the workshop. The manufacturer accepts no responsibility for any damage caused through use in a domestic setting.

---

## Operators, maintenance personnel



**NOTE!** The device must only be used by 1 person at a time. It is also necessary to ensure that no-one else is within the working area of the device when the device is being used.



**NOTE!** The device must only be serviced by 1 person at a time. It is also necessary to ensure that no-one else is within the working area of the device when the device is being worked on.

---

## Setup regulations



**WARNING!** If one of these devices falls or topples over, it could cause serious or even fatal injury. Bolt the device to a solid and level surface.



**NOTE!** The torch neck changeover station must be incorporated into a higher-level safety system within a secured area.

If this area has to be accessed when setup and maintenance work is carried out, make sure that

- the entire system is switched off for the duration of the work in this area
- and that it is prevented from starting up accidentally, e.g. as the result of a control fault

The device is tested to IP 20, meaning:

- protection against penetration by solid foreign bodies with diameters > 12.5 mm (0.49 in.)

### Dust

Make sure that metallic dust cannot accumulate directly on the device (from grinding work, for example).

### Outdoor operation

The device must not be set up and operated outdoors. The device does not offer protection against penetrating water and is only intended for indoor use.

---

## Specifications for water-cooled hosepacks

To ensure that the torch neck changeover system functions correctly, filter any dirt particles larger than 100 µm out of the coolant.

# Compressed air supply requirements

---


## **Compressed air supply specifications**

To ensure that the torch neck changeover system functions correctly, the following compressed air supply specifications must be met:

- Compressed air is free of oil
- Compressed air is free of dust - no dirt particles larger than 5 µm
- Compressed air is free of water
- Compressed air supply at 5.50 - 6.00 bar (79.77 - 87.02 psi)
- Minimum inner diameter of compressed air lines 5.5 mm (0.22 in.)

# Application example

## Application example




**NOTE!** Irrespective of the overall welding system setup

- adhere to the compressed air specifications
- provide the compressed air supply to the wire-feed unit and the torch neck changeover station as shown

(1) Compressed air supply line 5.50 - 6.00 bar (79.77 - 87.02 psi)	(10) Torch neck changeover station with interface
(2) Compressed air supply line for wire-feed unit max. 6.00 bar (87.02 psi)	(11) Data cable
(3) Wire-feed unit	(12) Robot
(4) Junction valve	(13) Drum coil
(5) Compressed air supply line from torch neck changeover station to torch neck coupling on the robot 13 bar (174.05 psi)	(14) Power source with cooling unit
(6) Hosepack with torch neck coupling and Robacta TX torch neck	(15) Power source interface
(7) Compressed air maintenance unit with filter	(16) Data cable
(8) Compressed air supply line for torch neck changeover station 5.50 - 6.00 bar (79.77 - 87.02 psi)	(17) Robot control
(9) Y-distributor	

# Bolt torch neck changeover station to the underlying surface (foundation)


## Safety

 **WARNING!** Risk of severe injury from mechanically powered parts. The torch neck changeover station must remain depressurised and de-energised until installation has been completed.

## Bolt torch neck changeover station to the underlying surface (foundation)



**NOTE!** Depending on the underlying surface (foundation), different wall plugs and screws are needed to bolt down the torch neck changeover station. Wall plugs and screws are therefore not included in the scope of supply of the torch neck changeover station. The installer is responsible for selecting the right wall plugs and screws.



- 1** Set up torch neck changeover station in a suitable location
- 2** If necessary, align the torch neck changeover station horizontally and vertically using adjustment plates
- 3** Bolt the torch neck changeover station bases (1) to the underlying surface (foundation) using four screws
- 4** Once bolted down, check whether the torch neck changeover station is horizontally and vertically aligned with the underlying surface

# Installing the torch neck changeover station - in conjunction with VR 7000 / VR 7000 CMT

## Safety




**WARNING!** Risk of severe injury from mechanically powered parts. The torch neck changeover station must remain depressurised and de-energised until installation has been completed.

## General




**NOTE!** For wire-feed units with the "Welding torch gas purging" option, limit the gas purging pressure to max. 6.00 bar (87.02 psi).


## Preparation




- 1 Place junction valve (1) on the fitting panel (2) as shown




- 2 Secure junction valve as shown using the screws, washers and nuts provided



- 3 Undo screw (3)
- 4 Disconnect compressed air line from the gas purging option connection (4)




- 5 Fit fitting panel and junction valve onto wire-feed unit and secure using the TX 25 screw (5) provided



- 6 Insert the supplied compressed air line with an outer diameter of 6 mm into connection (6) on the junction valve and into the gas purging option connection (7)


**Installing the  
torch neck  
changeover sta-  
tion**




- 1** Insert compressed air line into compressed air connection "A" on the torch neck changeover station and into connection (1) on the junction valve
- 2** Insert gas purging line from the hose-pack (2) into connection (3) on the junction valve

# Installing the torch neck changeover station - in conjunction with VR 1500 / VR 1530 / VR 1550


## Safety

 **WARNING!** Risk of severe injury from mechanically powered parts. The torch neck changeover station must remain depressurised and de-energised until installation has been completed.


## General

 **NOTE!** For wire-feed units with the "Welding torch gas purging" option, limit the gas purging pressure to max. 6.00 bar (87.02 psi).

## Preparation




**1** Secure junction valve (1) on the fitting panel (2) as shown using the screws, washers and nuts provided




**2** Undo screws (3)  
**3** Disconnect compressed air line from welding torch gas purging connection (4)






- 4 Fit fitting panel and junction valve onto wire-feed unit and secure using 2 TX 25 screws (5) provided



- 5 Insert the supplied compressed air line with an outer diameter of 6 mm into connection (6) on the junction valve and into the welding torch gas purging connection (7)


### Installing the torch neck changeover station




- 1 Insert compressed air line into compressed air connection "A" on the torch neck changeover station and into connection (1) on the junction valve
- 2 Insert gas purging line from the hose-pack (2) into connection (3) on the junction valve

# Installing the torch neck changeover station - in conjunction with VR 1500-PAP


## Safety

 **WARNING!** Risk of severe injury from mechanically powered parts. The torch neck changeover station must remain depressurised and de-energised until installation has been completed.


## General

 **NOTE!** For wire-feed units with the "Welding torch gas purging" option, limit the gas purging pressure to max. 6.00 bar (87.02 psi).


## Preparation




- 1 Unscrew compressed air connection (1) from junction valve
- 2 Screw compressed air connection provided (2) into junction valve as shown
  - Seal the compressed air connection using thread sealing tape




- 3 Secure junction valve on the fitting panel (2) as shown using the screws (3), washers and nuts provided



- 4** Undo screws (4) on the wire-feed unit




- 5** Disconnect compressed air line from welding torch gas purging connection (5)
- 6** Fit fitting panel and junction valve onto wire-feed unit and secure using 2 TX 25 screws (6) provided



- 7** Insert the compressed air line with an outer diameter of 8 mm into the welding torch gas purging connection (7) and into connection (8) on the junction valve
- 8** Insert gas purging line from the hose-pack (9) into connection (10) on the junction valve

**Installing the torch neck changeover station**



- 1** Insert compressed air line into compressed air connection "A" on the torch neck changeover station and into connection (1) on the junction valve


# Checking the torch neck sensor, setting the wire sensor

## Safety




**WARNING!** Risk of severe injury from mechanically powered parts. The torch neck changeover station must remain depressurised until installation has been completed.

## Checking the torch neck sensor



- 1 Establish a connection with the robot control. Depending on the system configuration:
  - using the standard I/O connecting plug for the robot control
  - or using a field bus coupler (see "Profinet Robacta TX" operating instructions)
- 2 Insert torch neck as far as it will go into the torch neck rack (1)




- LED (2) comes on
- A signal is sent to the robot control

If the above points do not apply:

- 3 Check whether the torch neck sensor is connected to the PC board


### Setting the wire sensor




- 1** Rotate the wire electrode in the opening (2) of the wire sensor (1) during the entire setting process
  - LED (4) comes on if the wire sensor (1) detects the wire electrode
- 2** Turn the adjusting screw (3) in the reverse direction until the LED (4) goes off
  - Wire sensor is deactivated
- 3** Only turn the adjusting screw (3) until the LED (4) comes on again
  - Wire sensor (1) is now set at the lowest sensitivity level
  - This prevents the wire sensor from being triggered accidentally

# Preparing torch neck with steel inner liner


## Preparing the torch neck




- 1 Insert inner liner (1) as far as it will go into the torch neck
- 2 Push the cutting aid (2) as far as it will go onto the inner liner
- 3 Tighten the locking screw (3) of the cutting aid
- 4 Pull the inner liner (1) and cutting aid (2) out of the torch neck
  - do not change the position of the cutting aid on the inner liner



- 5 Cut off the inner liner at the end of the cutting aid (2) using cutting pliers



- 6 Deburr the inner liner at both ends




- 7 Insert the inner liner into the torch neck
- 8 Insert the TX inlet/outlet nozzle (4) fully into the torch neck
  - Press down the TX inlet/outlet nozzle until you hear a click




# Preparing the torch neck with plastic inner liner


## Preparing the torch neck




- 1 Insert inner liner (1) as far as it will go into the torch neck
- 2 Push the cutting aid (2) as far as it will go onto the inner liner
- 3 Tighten the locking screw (3) of the cutting aid
- 4 Pull the inner liner (1) and cutting aid (2) out of the torch neck
  - do not change the position of the cutting aid on the inner liner



- 5 Cut off the inner liner at the end of the cutting aid (2) using a knife



- 6 Deburr the inner liner at both ends



- 7 Insert the inner liner into the torch neck
- 8 Insert the TX inlet/outlet nozzle (4) fully into the torch neck
  - Press down the TX inlet/outlet nozzle until you hear a click

# Preparing system components for Robacta hosepacks

## Safety



**WARNING!** Machines that start up automatically can cause serious injury and damage. In addition to these operating instructions, the safety rules issued by the manufacturers of the robot and welding systems must also be observed. For your personal safety, ensure that all protective measures have been taken and will remain in place for the duration of your stay within the working area of the robot.




**CAUTION!** Risk of burns from hot torch neck, hot torch neck coupling and other hot welding torch components. Before carrying out work, allow the torch neck, torch neck coupling and all other welding torch components to cool down to room temperature (+25 °C, +77 °F).




**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised until all work is completed.


## Preparing the torch neck coupling for Robacta hosepacks




- 1 Press centre bolt (1) out of the torch neck coupling (2)




- 2 Unscrew run-off plate (3) from centre bolt
  - using a 6 mm socket wrench insert



- 3 Remove grub screw (4) from centre bolt
  - using 1.5mm Allen key (5)



- 4 Screw run-off plate (3) into centre bolt




- 5 Push centre bolt (1) into torch neck coupling (2)

**Preparing the inner liner for Robacta hosepacks**




**NOTE!** More detailed information about fitting the inner liner can be found in the Robacta hosepack operating instructions.




- 1** Fit the inner liner as described in the Robacta hosepack operating instructions, but do not cut it yet
- 2** Cut the inner liner as shown
  - follow the instructions for cutting the inner liner as described in the Robacta hosepack operating instructions
- 3** Deburr inner liner
  - follow the instructions for deburring the inner liner as described in the Robacta hosepack operating instructions

# Preparing the torch neck coupling for Robacta Drive and Robacta Drive CMT hosepacks with steel inner liners


Preparing the torch neck coupling for Robacta Drive and Robacta Drive CMT hosepacks



- 1 Insert the inner liner from the original equipment kit of the hosepack being used (1) as far as it will go into the torch neck coupling (2) as shown
- 2 Insert cutting pipe (3) of the hosepack being used onto the inner liner  
- Cutting pipe item number:  
42,0001,5910
- 3 Cut off the inner liner (1) at the end of the cutting pipe (3) using cutting pliers
- 4 Remove the cutting pipe (3)




- 5 Remove inner liner from the torch neck coupling
- 6 Deburr the inner liner at both ends




- 7 Insert deburred inner liner (1) as far as it will go into the torch neck coupling

# Preparing the torch neck coupling for Robacta Drive and Robacta Drive CMT hosepacks with plastic inner liners


## Preparing the torch neck coupling for Robacta Drive and Robacta Drive CMT hosepacks



- 1 Insert the inner liner from the original equipment kit of the hosepack being used (1) as far as it will go into the torch neck coupling (2) as shown
- 2 Insert cutting pipe (3) of the hosepack being used onto the inner liner  
- Cutting pipe item number:  
42,0001,5910
- 3 Cut off the inner liner (1) at the end of the cutting pipe (3) using a knife
- 4 Remove the cutting pipe (3)



- 5 Remove inner liner from the torch neck coupling
- 6 Deburr the inner liner at both ends



- 7 Insert deburred inner liner (1) as far as it will go into the torch neck coupling

# Preparing the power source

---

## Preparing the power source

- 1 On the power source being used, create a new job for moving the wire electrode forwards and backwards
  - Wire threading speed: 600 cm/min (236.22 ipm)
- 2 Set filter time for flow watchdog to 25 seconds using RCU 5000 i



# Fitting the torch neck coupling

## Safety



**WARNING!** Machines that start up automatically can cause serious injury and damage. In addition to these operating instructions, the safety rules issued by the manufacturers of the robot and welding systems must also be observed. For your personal safety, ensure that all protective measures have been taken and will remain in place for the duration of your stay within the working area of the robot.



**CAUTION!** Risk of burns from hot torch neck, hot torch neck coupling and other hot welding torch components. Before carrying out work, allow the torch neck, torch neck coupling and all other welding torch components to cool down to room temperature (+25 °C, +77 °F).



**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised until all work is completed.

## Fitting the torch neck coupling




**NOTE!** When fitting the torch neck coupling, the TCP moves by 50 mm (1.97 in.).

### For Robacta Drive and Robacta Drive CMT drive units:

- 1 Push centre bolt (1) approx. 5 mm (0.2 in.) out of torch neck coupling (2) as shown
- 2 Position torch neck coupling (2) and inner liner onto drive unit
- 3 Screw torch neck coupling (2) as far as possible onto drive unit by hand
- 4 Tighten torch neck coupling (3) using installation tool (4)
  - Tightening torque = 30 Nm

### For Robacta hosepacks:

- 1 Push centre bolt (1) approx. 5 mm out of torch neck coupling (2) as shown
- 2 Fit torch neck coupling (2) without inner liner onto drive unit
  - The inner liner must have already been properly prepared in the hosepack before the torch neck coupling can be fitted onto the hosepack
- 3 Screw torch neck coupling (2) as far as possible onto drive unit by hand
- 4 Tighten torch neck coupling (3) using installation tool (4)
  - Tightening torque = 30 Nm




# Configuring torch neck for special rack positions

## General

- The torch neck is configured at the factory in such a way that the end of the torch neck points away from the torch neck changeover station when the torch neck is deposited in the torch neck rack.
- The direction in which the end of the torch neck is pointing depends on the position in which the torch neck is bolted to the torch neck insulation.
- To change the alignment of the torch neck in the torch neck rack, fit the torch neck insulation in 90° steps.

## Turning the torch neck insulation



- 1 Undo all grub screws on the edge of the torch neck (1)
  - 2 Push torch neck insulation (2) down approx. 50 mm
  - 3 Fit assembly aid (3) onto torch neck
  - 4 Turn torch neck insulation (2) as required and push it as far as it will go onto the torch neck
- NOTE!** Always tighten the opposite grub screw. Do not tighten grub screws one-by-one in a circular fashion
- 5 Tighten all grub screws on the edge of the torch neck (1) using an Allen key
    - Tightening torque = 0.15 Nm


# Connecting and adjusting the compressed air amplifier

## General




**NOTE!** When using the maintenance unit option, connect and adjust the compressed air amplifier as per the "Maintenance unit" section in the "Robacta TX options" fitting instructions.

## Connecting the compressed air amplifier




- 1** Screw a compressed air connection that is suitable for the compressed air supply line into the compressed air connection "B" on the torch neck changeover station
  - Seal the compressed air connection using thread sealing tape
- 2** Depressurise the compressed air supply line and make sure that this compressed air supply line remains depressurised for the duration of the work on the device
- 3** Connect compressed air supply line to compressed air connection "B" on the torch neck changeover station
- 4** Feed compressed air into the compressed air supply line
- 5** Undo the 8 screws (1)
- 6** Remove lid (2)

### Adjusting the compressed air amplifier



- 1 Pull control dial (1) to unlock it
- 2 Turn the control dial (1) until the pressure gauge (2) shows 1.3 MPa
  - = 13 bar
  - = 188.55 psi
  - if necessary in the case of long hosepacks, set the pressure to max. 1.6 MPa (=16 bar = 232.06 psi)
- 3 Press control dial (1) to lock it

### And finally...



- 1 Place the lid (2) on the torch neck changeover station
- 2 Tighten 8 screws (1)

# Changing the torch neck manually

---

## Safety



**WARNING!** Machines that start up automatically can cause serious injury and damage. In addition to these operating instructions, the safety rules issued by the manufacturers of the robot and welding systems must also be observed. For your personal safety, ensure that all protective measures have been taken and will remain in place for the duration of your stay within the working area of the robot.



**CAUTION!** Risk of injury from escaping compressed air and flying parts from the torch neck coupling. When manually changing the torch neck, always wear the following protective equipment:

- Ear protection
- Protective goggles with side protection
- Gloves - electrically insulated and providing protection against heat



**CAUTION!** Risk of burns from hot torch neck, hot torch neck coupling and other hot welding torch components. Before carrying out work, allow the torch neck, torch neck coupling and all other welding torch components to cool down to room temperature (+25 °C, +77 °F).

---


## Changing the torch neck manually





**WARNING!** Risk of severe injury from the robot arm and the tip of the robot programming aid. During the course of the whole process:

- carry out all work outside of the robot working area
- make sure there is no one else within the robot working area

- 1 When carrying out the following work, position the robot arm and the torch neck coupling so that
  - the Unlock/Lock button on the torch neck changeover station can be pressed with one hand
  - the torch neck can be placed onto or removed from the torch neck coupling with the other hand




- 2** Hold the torch neck on the robot arm with one hand
- 3** Press and hold the Unlock/Lock button (1) on the torch neck changeover station
  - Torch neck coupling lock (2) opens
- 4** Remove torch neck from torch neck coupling
- 5** Place torch neck back onto the torch neck coupling, press against the torch neck coupling and hold in this position
- 6** Release the Unlock/Lock button on the torch neck changeover station
  - Lock closes
  - Torch neck is fixed after approx. 5 seconds



- 7** Check that the gap between the torch neck (3) and the torch neck coupling (4) is the same around the entire perimeter
- 8** Shake and pull the torch neck with your hand
  - if the torch neck does not come off the torch neck coupling, then the connection between the torch neck and the torch neck coupling is OK
  - if the torch neck does come off, repeat steps 1 - 8

# Setting up the robot

Dimensions of the rack holder including torch neck racks



## Safety



**WARNING!** Machines that start up automatically can cause serious injury and damage. In addition to these operating instructions, the safety rules issued by the manufacturers of the robot and welding systems must also be observed. For your personal safety, ensure that all protective measures have been taken and will remain in place for the duration of your stay within the working area of the robot.



**CAUTION!** Risk of injury from escaping compressed air and flying parts from the torch neck coupling. During the activities described below, always wear the following protective equipment:

- Ear protection
- Protective goggles with side protection
- Gloves - electrically insulated and providing protection against heat




**CAUTION!** Risk of burns from hot torch neck, hot torch neck coupling and other hot welding torch components. Before carrying out work, allow the torch neck, torch neck coupling and all other welding torch components to cool down to room temperature (+25 °C, +77 °F).

**Determining the TCP of the welding torch, determining the X-axis and Y-axis of the torch neck changeover station**

**WARNING!** Risk of severe injury from protruding TCP tips. During the course of the whole process:

- do not touch the TCP tips
- make sure that no one else touches the TCP tips



- 1 Screw 3 TCP tips into the holes (1) of the rack holder
- 2 Measure TCP of the welding torch being used
- 3 Determine the X-axis and Y-axis of the torch neck changeover station using the TCP tips and record in the coordinate system of the robot
- 4 Set up the robot

**Fitting the robot programming aid**

**WARNING!** Risk of severe injury from the tip of the robot programming aid. During the course of the whole process:


- wear protective gloves
- do not touch the tip of the robot programming aid
- make sure that no one else touches the tip of the robot programming aid

**WARNING!** Risk of severe injury from the robot arm. During the course of the whole process:


- carry out all work outside of the robot working area
- make sure there is no one else within the robot working area

- 1 When carrying out the following work, position the robot arm and the torch neck coupling so that
  - the Unlock/Lock button on the torch neck changeover station can be pressed with one hand
  - the torch neck can be placed onto or removed from the torch neck coupling with the other hand
- 2 Hold the torch neck on the robot arm with one hand







- 3** Press and hold the Unlock/Lock button (1) on the torch neck changeover station
  - torch neck coupling lock opens
- 4** Remove torch neck from torch neck coupling



- 5** Place both parts of the robot programming aid (2) onto the torch neck coupling on the robot (3) and hold in place
- 6** Release the Unlock/Lock button on the torch neck changeover station
  - Lock closes
  - the robot programming aid is fixed after approx. 5 seconds



- 7** Place the bottom part of the robot programming aid (4) into the first torch neck rack (5) on the torch neck changeover station as shown



**WARNING!** Risk of severe injury from the tip of the robot programming aid. With regard to the robot programming aid

- only touch it wearing protective gloves
- only touch its exterior surfaces (7)


**8** Shake and pull the robot programming aid with your hand

- if the robot programming aid does not come off the torch neck coupling, then the connection between the robot programming aid and the torch neck coupling is OK
- if the robot programming aid does come off, repeat steps 1 - 8


**Setting up the robot**

**WARNING!** Risk of severe injury from the robot arm and the tip of the robot programming aid. During the course of the whole process:

- carry out all work outside of the robot working area
- make sure there is no one else within the robot working area



**1** Measure TCP of the robot programming aid




**2** Move the robot into the second part of the robot programming aid (6), leaving a gap of approx. 15 mm (0.59 in.)

Check the following:

- both parts of the robot programming aid must be the same distance to each other around the entire perimeter

**3** Save this position for later use as position H in the program sequence


- see "Program sequence" section



- 4** Move the robot into the second part of the robot programming aid, leaving a gap of approx. 1.5 mm (0.06 in.)

Check the following:

- both parts of the robot programming aid must be the same distance to each other around the entire perimeter
- the edges of both parts of the robot programming aid must lie flush to each other



- 5** Move the robot into the second part of the robot programming aid until both parts are on top of each other
- end position has been reached
- 6** Save this position for later use as position G in the program sequence
- see "Program sequence" section
- 7** Create robot program for this torch neck rack position as per the program sequence
- 8** Carry out steps 1 - 9 for all other torch neck rack positions
- 9** Remove the TCP tips from the rack holder and store in such a way that there is no risk of injury

# Start-up

---

## Prerequisites for start-up

The following prerequisites must be fulfilled for the start-up:

- When using a Robacta Drive or Robacta Drive CMT hosepack, the torch neck coupling has been prepared
- When using a Robacta hosepack, the inner liner and torch neck coupling have been prepared
- Torch necks configured for special rack positions (only if necessary)
- All torch necks have been prepared
- Torch neck changeover station bolted to the underlying surface
- Torch neck changeover station installed
- All torch neck sensors checked, wire sensor set
- Torch neck coupling mounted onto robot
- Power source has been prepared
- Compressed air amplifier adjusted
- Torch neck change performed manually
- Robot set up using robot programming aid

---

## Start-up

The torch neck changeover station is started up by an active signal from the robot control.



# **Program sequence**



# Program sequence

## Speed data for the program sequence

A list of all speeds and corresponding units in the program sequence:

cm/min	=	m/s	=	ipm
1000	=	0.17	=	393.70
600	=	0.1	=	236.22
100	=	0.017	=	39.37
70	=	0.012	=	27.56
50	=	0.008	=	19.69
35	=	0.006	=	13.78
30	=	0.005	=	11.81


## Subprograms in the program sequence


To facilitate programming, the program sequence is split into the following subprograms:


- cut wire electrode
- wind back wire electrode
- set down torch neck
- pick up torch neck
- unwind wire electrode





**Program sequence**

















# Troubleshooting





## Safety



**NOTE!** Observe the following safety instructions for all work described in the "Troubleshooting" section.



**WARNING!** Work that is carried out incorrectly can cause serious injury or damage. The activities described below must only be carried out by trained and qualified personnel. Do not carry out the activities described below until you have fully read and understood the following documents:

- these operating instructions
- all the operating instructions for the system components, especially the safety rules



**WARNING!** Machines that start up automatically can cause serious injury and damage. In addition to these operating instructions, the safety rules issued by the manufacturers of the robot and welding systems must also be observed. For your personal safety, ensure that all protective measures have been taken and will remain in place for the duration of your stay within the working area of the robot.



**WARNING!** Risk of severe injury from mechanically powered parts. The torch neck changeover station must remain depressurised and de-energised until all work is completed.



**WARNING!** Work that is carried out incorrectly can cause serious injury or damage. Before starting work:

- turn the power source mains switch to the "O" position
- disconnect the power source from the mains
- put up an easy-to-understand warning sign to stop anybody inadvertently switching it back on again



**CAUTION!** Risk of injury from sharp flying parts. During the work described below, always wear the following protective equipment:

- Protective goggles with side protection
- Ear protection
- Gloves - electrically insulated and providing protection against heat



**CAUTION!** Risk of burns from hot torch neck, hot torch neck coupling and other hot welding torch components. Before carrying out work, allow the torch neck, torch neck coupling and all other welding torch components to cool down to room temperature (+25 °C, +77 °F).

# Troubleshooting

---

## Troubleshooting

---

**Torch neck unexpectedly loses contact with the torch neck coupling during gas purging**

Cause: Gas purging pressure too high

Remedy: Adjust gas purging pressure

---

**Torch neck unexpectedly loses contact with the torch neck coupling during gas purging**

Cause: Gas hole in centre bolt dirty

Remedy: Clean gas hole in centre bolt - see "Cleaning the gas hole" section in the operating instructions

---

**After a torch neck has been changed, there is some residual coolant on the torch neck**

Cause: Coolant hoses incorrectly connected to the cooling unit

Remedy: Connect the coolant hoses to the cooling unit in the right direction for the coolant flow

---

**After a torch neck has been changed, there is some residual coolant on the torch neck**

Cause: Torch neck coupling worn

Remedy: Send the torch neck coupling to the manufacturer's service department

---

**After a torch neck has been changed, there is some residual coolant on the torch neck**

Cause: Robot speed too fast when picking up and setting down the torch neck

Remedy: Reduce robot speed when picking up and setting down the torch neck

---

**After a torch neck has been changed, there is some residual coolant on the torch neck**

Cause: Compressed air escaping from the torch neck coupling is causing coolant to be blown out of the set down torch neck when locking the torch neck coupling

Remedy: Lock the torch neck coupling next to the torch neck changeover station

---

**After the torch neck has been set down, coolant sprays out of the torch neck**

Cause: Torch neck very hot

Remedy: Use water-cooled gas nozzle

---

**RCU 5000i outputs the error message "No coolant flow out / power source outputs the error message no | H2O"**

Cause: Cooling unit flow watchdog has been triggered

Remedy: Set filter time for flow watchdog to 25 seconds using RCU 5000i

---

**Torch neck coupling does not open**

Cause: Compressed air supply to torch neck changeover station briefly too low

Remedy: Change torch neck manually (see operating instructions, "Manually changing the torch neck" section)

---

**Torch neck coupling does not open**

Cause: Very long hosepacks

Remedy: Increase pressure to max. 1.6 MPa (= 16 bar = 232.06 psi) for the compressed air amplifier

---

**Torch neck coupling does not open**

Cause: Compressed air supply of torch neck changeover station too low

Remedy: Ensure compressed air supply is as per the specifications in the operating instructions

---

**Torch neck coupling does not open**

Cause: Incorrect output pressure set on the compressed air amplifier

Remedy: Adjust compressed air amplifier as per the specifications in the operating instructions

---

**Torch neck coupling does not open**

Cause: Torch neck coupling is faulty

Remedy: Press the emergency release button and service the centre bolt as per the operating instructions. If this does not remedy the problem, send the torch neck coupling to the manufacturer's service department.

---



# **Care, maintenance and disposal**



## Safety



**NOTE!** Observe the following safety instructions for all work described in the "Care, maintenance and disposal" section.



**WARNING!** Work that is carried out incorrectly can cause serious injury or damage. The activities described below must only be carried out by trained and qualified personnel. Do not carry out the activities described below until you have fully read and understood the following documents:

- these operating instructions
- all the operating instructions for the system components, especially the safety rules



**WARNING!** Machines that start up automatically can cause serious injury and damage. In addition to these operating instructions, the safety rules issued by the manufacturers of the robot and welding systems must also be observed. For your personal safety, ensure that all protective measures have been taken and will remain in place for the duration of your stay within the working area of the robot.



**WARNING!** Work that is carried out incorrectly can cause serious injury or damage. Before starting work:

- turn the power source mains switch to the "O" position
- disconnect the power source from the mains
- put up an easy-to-understand warning sign to stop anybody inadvertently switching it back on again



**CAUTION!** Risk of injury from escaping compressed air and sharp flying parts. During the work described below, always wear the following protective equipment:

- Protective goggles with side protection
- Ear protection
- Gloves - electrically insulated and providing protection against heat



**CAUTION!** Risk of burns from hot torch neck, hot torch neck coupling and other hot welding torch components. Before carrying out work, allow the torch neck, torch neck coupling and all other welding torch components to cool down to room temperature (+25 °C, +77 °F).



# Maintenance for each torch neck service, at least weekly

---

## Preparation

- 1 When carrying out the following work, position the robot arm so that
  - the Unlock/Lock button on the torch neck changeover station can be pressed with one hand
  - the torch neck can be removed from or placed onto the torch neck coupling with the other hand
- 2 Feed out the wire electrode from the hosepack
- 3 Hold torch neck with one hand
- 4 Press the Unlock/Lock button on the torch neck changeover station
  - torch neck coupling lock opens
- 5 Remove torch neck from the torch neck coupling
- 6 Depressurise the compressed air supply line to the torch neck changeover station and make sure that this compressed air line remains depressurised for the duration of the work on the device
- 7 Disconnect the compressed air line from compressed air connection "A" on the torch neck changeover station



**CAUTION!** Risk of injury from escaping compressed air from compressed air connection "A". Compressed air emerges at up to 16 bar (232.06 psi) from compressed air connection "A" when the Unlock/Lock button is pressed. While compressed air is emerging from connection "A":

- wear ear protection
- keep the face and all other body parts away from connection "A"
- ensure that no other persons are in the vicinity of the torch neck changeover station

- 8 Press and hold the Unlock/Lock button on the torch neck changeover station until compressed air no longer emerges from compressed air connection "A" on the torch neck changeover station
  - compressed air amplifier in the torch neck changeover station discharges
- 9 De-energise the torch neck changeover station


---

## Safety




**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised and de-energised until all work is completed.


**Checking the torch neck for damage and wear**



- Check wire guide pin (1) for damage
- Check coolant pin (2) for damage
- Check gas pin (3) for damage
- If a component is damaged, send the entire torch neck coupling to the manufacturer's service department




- Check the TX inlet/outlet nozzle (4) for wear and replace if necessary
- Check the O-ring (5) on the wire guide pin for damage and replace if necessary
- Check the O-ring (6) on the gas guide pin for damage and replace if necessary



- Check that the torch neck insulation (7) is secure


### Checking the torch neck coupling




- Check the surface within the marked area (1) for dirt
  - If dirty, clean the marked area and eliminate the cause of the dirt
- Check the surface within the marked area (1) for damage
  - If damaged, send the entire torch neck coupling to the manufacturer's service department

- Check whether there is coolant residue on the surface within the marked area (1)
  - If there is, replace the coolant stops
- For Robacta Drive and Robacta Drive CMT hosepacks only:  
check the inner liner of the centre bolt for wear and damage and replace if necessary


### Changing the steel inner liner in the torch neck




- 1 Remove the gas nozzle from the torch neck
- 2 Unscrew the contact tip (1) from the torch neck



- 3 Unscrew the spatter guard (2) from the torch neck




**4** Unscrew the nozzle fitting (3) from the torch neck



**5** Remove the inner liner and TX inlet/outlet nozzle (4) from the torch neck  
- Keep TX inlet/outlet nozzle for re-fitting at a later stage

**6** Put the nozzle fitting, spatter guard, contact tip and gas nozzle back on again




**7** Insert inner liner (5) as far as it will go into the torch neck


**8** Push the cutting aid (6) as far as it will go onto the inner liner

**9** Tighten the locking screw (7) of the cutting aid


**10** Pull the inner liner (5) and cutting aid (6) out of the torch neck  
- do not change the position of the cutting aid on the inner liner



- 11** Cut off the inner liner at the end of the cutting aid (8) using cutting pliers



- 12** Deburr the inner liner at both ends



- 13** Insert the inner liner into the torch neck




**NOTE!** Replace the TX inlet/outlet nozzle if:

- no click is heard when fitting
- the TX inlet/outlet nozzle is worn


- 14** Insert the TX inlet/outlet nozzle (4) fully into the torch neck

- Press down the TX inlet/outlet nozzle until you hear a click


**Changing the plastic inner liner in the torch neck**




- 1** Remove the gas nozzle from the torch neck
- 2** Unscrew the contact tip (1) from the torch neck




- 3** Unscrew the spatter guard (2) from the torch neck




- 4** Unscrew the nozzle fitting (3) from the torch neck




- 5** Remove the inner liner and TX inlet/outlet nozzle (4) from the torch neck
  - Keep TX inlet/outlet nozzle for re-fitting at a later stage
- 6** Put the nozzle fitting, spatter guard, contact tip and gas nozzle back on again




- 7** Insert inner liner (5) as far as it will go into the torch neck
- 8** Push the cutting aid (6) as far as it will go onto the inner liner
- 9** Tighten the locking screw (7) of the cutting aid
- 10** Pull the inner liner (5) and cutting aid (6) out of the torch neck
  - do not change the position of the cutting aid on the inner liner



- 11** Cut off the inner liner at the end of the cutting aid (8)



**12** Deburr the inner liner at both ends



**13** Insert the inner liner into the torch neck



**NOTE!** Replace the TX inlet/outlet nozzle if:

- no click is heard when fitting
- the TX inlet/outlet nozzle is worn

**14** Insert the TX inlet/outlet nozzle (4) fully into the torch neck

- Press down the TX inlet/outlet nozzle until you hear a click

### And finally...

- 1** Thread the wire electrode into the hosepack
- 2** Connect the compressed air line to compressed air connection "A" on the torch neck changeover station
- 3** Establish the compressed air and power supply to the torch neck changeover station
- 4** Place the torch neck correctly onto the torch neck coupling



# Monthly maintenance - changing the inner liner in the centre bolt

---

## Preparation

- 1 When carrying out the following work, position the robot arm so that
  - the Unlock/Lock button on the torch neck changeover station can be pressed with one hand
  - the torch neck can be removed from or placed onto the torch neck coupling with the other hand
- 2 Feed out the wire electrode from the hosepack
- 3 Hold torch neck with one hand
- 4 Press the Unlock/Lock button on the torch neck changeover station
  - torch neck coupling lock opens
- 5 Remove torch neck from the torch neck coupling
- 6 Depressurise the compressed air supply line to the torch neck changeover station and make sure that this compressed air line remains depressurised for the duration of the work on the device
- 7 Disconnect the compressed air line from compressed air connection "A" on the torch neck changeover station



**CAUTION!** Risk of injury from escaping compressed air from compressed air connection "A". Compressed air emerges at up to 16 bar (232.06 psi) from compressed air connection "A" when the Unlock/Lock button is pressed. While compressed air is emerging from connection "A":

- wear ear protection
- keep the face and all other body parts away from connection "A"
- ensure that no other persons are in the vicinity of the torch neck changeover station

- 8 Press and hold the Unlock/Lock button on the torch neck changeover station until compressed air no longer emerges from compressed air connection "A" on the torch neck changeover station
  - compressed air amplifier in the torch neck changeover station discharges
- 9 De-energise the torch neck changeover station


---

## Safety




**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised and de-energised until all work is completed.


**Changing the steel inner liners for Robacta Drive and Robacta Drive CMT hosepacks**




- 1** Unscrew run-off plate (1) from centre bolt (2)
  - using a 6 mm socket wrench insert
- 2** Remove run-off plate (1) and worn inner liner from centre bolt (2)



- 3** Cut new inner liner using cutting pliers
  - Robacta Drive = 96 mm (3.78 in.)
  - Robacta Drive CMT = 80 mm (3.15 in.)




- 4** Deburr the inner liner at both ends




- 5 Insert inner liner (3) into run-off plate (1)
- 6 Screw run-off plate and inner liner into centre bolt


**Changing the plastic inner liners for Robacta Drive and Robacta Drive CMT hosepacks**




- 1 Unscrew run-off plate (1) from centre bolt (2)
  - using a 6 mm socket wrench insert
- 2 Remove run-off plate (1) and worn inner liner from centre bolt (2)



- 3 Cut new inner liner using a knife
  - Robacta Drive = 96 mm (3.78 in.)
  - Robacta Drive CMT = 80 mm (3.15 in.)



**4** Deburr the inner liner at both ends



**5** Insert inner liner (3) into run-off plate (1)

**6** Screw run-off plate and inner liner into centre bolt

### And finally...

- 1** Thread the wire electrode into the hosepack
- 2** Connect the compressed air line to compressed air connection "A" on the torch neck changeover station
- 3** Establish the compressed air and power supply to the torch neck changeover station
- 4** Place the torch neck correctly onto the torch neck coupling

# Maintenance when required

---

## **Maintenance when required**

- Change coolant stops
  - to change the coolant stops, refer to the "Changing the coolant stops" section
- Service centre bolt
  - to service the centre bolt, refer to the "Servicing the centre bolt" section
- Clean gas hole
  - to clean the gas hole, refer to the "Cleaning the gas hole" section

# Servicing the centre bolt

## Preparation


- 1 When carrying out the following work, position the robot arm so that
  - the Unlock/Lock button on the torch neck changeover station can be pressed with one hand
  - the torch neck can be removed from or placed onto the torch neck coupling with the other hand
- 2 Feed out the wire electrode from the hosepack
- 3 Hold torch neck with one hand
- 4 Press the Unlock/Lock button on the torch neck changeover station
  - torch neck coupling lock opens
- 5 Remove torch neck from the torch neck coupling
- 6 Depressurise the compressed air supply line to the torch neck changeover station and make sure that this compressed air line remains depressurised for the duration of the work on the device
- 7 Disconnect the compressed air line from compressed air connection "A" on the torch neck changeover station



**CAUTION!** Risk of injury from escaping compressed air from compressed air connection "A". Compressed air emerges at up to 16 bar (232.06 psi) from compressed air connection "A" when the Unlock/Lock button is pressed. While compressed air is emerging from connection "A":

- wear ear protection
- keep the face and all other body parts away from connection "A"
- ensure that no other persons are in the vicinity of the torch neck changeover station

- 8 Press and hold the Unlock/Lock button on the torch neck changeover station until compressed air no longer emerges from compressed air connection "A" on the torch neck changeover station
  - compressed air amplifier in the torch neck changeover station discharges
- 9 De-energise the torch neck changeover station




- 10 Unscrew the torch neck coupling (1) from the robot arm using the installation tool (2)
- 11 Press centre bolt out of the torch neck coupling

## Safety




**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised and de-energised until all work is completed.


## Centre bolt




- Check gas pin (1) for damage
- Check coolant pin (2) for damage
- Check wire guide pin (3) for damage
- If a component is damaged, send the entire torch neck coupling to the manufacturer's service department



- Check the O-ring (4) on the gas pin for damage and replace if necessary
- Check the O-rings (5) on the coolant pin for damage and replace if necessary



- Check the O-ring (6) on the wire guide pin for damage and replace if necessary



- Check the O-rings (7) on the gas pin for damage and replace if necessary

- Check the torch neck changeover station for damage

---

**And finally...**

- 1 Thread the wire electrode into the hosepack
- 2 Connect the compressed air line to compressed air connection "A" on the torch neck changeover station
- 3 Establish the compressed air and power supply to the torch neck changeover station
- 4 Insert the centre bolt and inner liner into the torch neck coupling
- 5 Place the torch neck correctly onto the torch neck coupling



# Changing coolant stops

---

## Preparation

- 1 When carrying out the following work, position the robot arm so that
  - the Unlock/Lock button on the torch neck changeover station can be pressed with one hand
  - the torch neck can be removed from or placed onto the torch neck coupling with the other hand
- 2 Feed out the wire electrode from the hosepack
- 3 Hold torch neck with one hand
- 4 Press the Unlock/Lock button on the torch neck changeover station
  - torch neck coupling lock opens
- 5 Remove torch neck from the torch neck coupling
- 6 Depressurise the compressed air supply line to the torch neck changeover station and make sure that this compressed air line remains depressurised for the duration of the work on the device
- 7 Disconnect the compressed air line from compressed air connection "A" on the torch neck changeover station



**CAUTION!** Risk of injury from escaping compressed air from compressed air connection "A". Compressed air emerges at up to 16 bar (232.06 psi) from compressed air connection "A" when the Unlock/Lock button is pressed. While compressed air is emerging from connection "A":

- wear ear protection
- keep the face and all other body parts away from connection "A"
- ensure that no other persons are in the vicinity of the torch neck changeover station

- 8 Press and hold the Unlock/Lock button on the torch neck changeover station until compressed air no longer emerges from compressed air connection "A" on the torch neck changeover station
  - compressed air amplifier in the torch neck changeover station discharges
- 9 De-energise the torch neck changeover station


---

## Safety




**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised and de-energised until all work is completed.

### Removing coolant stops



- 1 Place the bit insert for coolant stops (1) onto the manual torque wrench (2)




- NOTE!** Push the bit insert on the manual torque wrench as far as it will go into the coolant stops.
- 2 Unscrew coolant stops (3) from the torch neck coupling using the manual torque wrench


### Preparing new coolant stops




- 1 Insert the 6 x 1.5 mm O-ring into the groove (1) on the inside of the coupling crown



- 2** Insert the 7 x 1 mm O-ring into the groove (2) on the outside of the coupling crown



- 3** Insert the 2 x 1 mm O-ring into the groove (3) on the coupling plunger




- 4** Insert the coupling valve (4) into the coupling crown (5)
- 5** Insert the spring (6) into the coupling crown (5)
- 6** Insert the coupling plunger (7) into the coupling crown (5)



- completed coolant stop

- 7 Carry out the steps listed above on the second coolant stop

### Fitting new coolant stops



**NOTE!** Fit the coolant stops as far as they will go onto the bit insert on the manual torque wrench.

- 1 Lightly lubricate the O-ring on the coolant stop
- 2 Fit the ready-made coolant stop onto the bit insert for the coolant stop (1) on the manual torque wrench
- 3 Insert the coolant stop into a hole (2) with a rotary movement
  - the rotary movement will not damage the O-ring
- 4 Tighten coolant stop
  - Tightening torque = 3 Nm
- 5 Repeat the steps listed above on the second coolant stop

### And finally...

- 1 Thread the wire electrode into the hosepack
- 2 Connect the compressed air line to compressed air connection "A" on the torch neck changeover station
- 3 Establish the compressed air and power supply to the torch neck changeover station
- 4 Place the torch neck correctly onto the torch neck coupling

# Cleaning the gas hole

## Preparation


- 1 When carrying out the following work, position the robot arm so that
  - the Unlock/Lock button on the torch neck changeover station can be pressed with one hand
  - the torch neck can be removed from or placed onto the torch neck coupling with the other hand
- 2 Feed out the wire electrode from the hosepack
- 3 Hold torch neck with one hand
- 4 Press the Unlock/Lock button on the torch neck changeover station
  - torch neck coupling lock opens
- 5 Remove torch neck from the torch neck coupling
- 6 Depressurise the compressed air supply line to the torch neck changeover station and make sure that this compressed air line remains depressurised for the duration of the work on the device
- 7 Disconnect the compressed air line from compressed air connection "A" on the torch neck changeover station



**CAUTION!** Risk of injury from escaping compressed air from compressed air connection "A". Compressed air emerges at up to 16 bar (232.06 psi) from compressed air connection "A" when the Unlock/Lock button is pressed. While compressed air is emerging from connection "A":

- wear ear protection
- keep the face and all other body parts away from connection "A"
- ensure that no other persons are in the vicinity of the torch neck changeover station

- 8 Press and hold the Unlock/Lock button on the torch neck changeover station until compressed air no longer emerges from compressed air connection "A" on the torch neck changeover station
  - compressed air amplifier in the torch neck changeover station discharges
- 9 De-energise the torch neck changeover station




- 10 Unscrew the torch neck coupling (1) from the robot arm using the installation tool (2)
- 11 Press centre bolt out of the torch neck coupling

## Safety




**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised and de-energised until all work is completed.


### Cleaning the gas hole




1 Unscrew the gas pin (1) from the centre bolt using the 5.5 mm socket wrench




2 Take the control slide valve (2) and spring under the control slide valve off the centre bolt




3 Clean the control slide valve (3) and spring (4)  
**NOTE!** Do not lubricate the spring and control slide valve.



- 4 Clean the hole (5)
- 5 Insert the spring and control slide valve back into the hole (5)

 **NOTE!** The spring and control slide valve must drop into the hole (5) without any resistance.



- 6 Screw the gas pin (1) into the centre bolt using a 5.5 mm socket wrench

---

**And finally...**

- 1 Thread the wire electrode into the hosepack
- 2 Connect the compressed air line to compressed air connection "A" on the torch neck changeover station
- 3 Establish the compressed air and power supply to the torch neck changeover station
- 4 Insert the centre bolt and inner liner into the torch neck coupling
- 5 Place the torch neck correctly onto the torch neck coupling

# Pressing the emergency release button

## General



**NOTE!** Only press the emergency release button:

- if the torch neck does not come off the torch neck coupling after the appropriate robot control command has been issued
- if the torch neck cannot be changed manually
- to remove the torch neck manually from the torch neck coupling, refer to "Manually changing the torch neck"

## Preparation

- 1 When carrying out the following work, position the robot arm so that
  - the Unlock/Lock button on the torch neck changeover station can be pressed with one hand
  - the torch neck can be removed from or placed onto the torch neck coupling with the other hand
- 2 Feed out the wire electrode from the hosepack
- 3 Depressurise the compressed air supply line to the torch neck changeover station and make sure that this compressed air line remains depressurised for the duration of the work on the device
- 4 Disconnect the compressed air line from compressed air connection "A" on the torch neck changeover station



**CAUTION!** Risk of injury from escaping compressed air from compressed air connection "A". Compressed air emerges at up to 16 bar (232.06 psi) from compressed air connection "A" when the Unlock/Lock button is pressed. While compressed air is emerging from connection "A":

- wear ear protection
- keep the face and all other body parts away from connection "A"
- ensure that no other persons are in the vicinity of the torch neck changeover station

- 5 Press and hold the Unlock/Lock button on the torch neck changeover station until compressed air no longer emerges from compressed air connection "A" on the torch neck changeover station
  - compressed air amplifier in the torch neck changeover station discharges
- 6 De-energise the torch neck changeover station


## Safety




**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised and de-energised until all work is completed.




**Pressing the emergency re-lease button**




- 1 Remove the plastic placeholder (1) from the plastic sleeve on the torch neck coupling (2)



- 2 Unscrew the grub screw (3) from the torch neck coupling using a 1.5 mm Allen key



-  **NOTE!** The opening in the plastic sleeve of the torch neck coupling must be directly above the exposed hole in the torch neck coupling.
- 3 Press the compressed air pistol (4) firmly into the plastic sleeve on the torch neck coupling
  - 4 Actuate the compressed air pistol and at the same time pull the torch neck off the torch neck coupling
  - 5 Send the torch neck coupling and centre bolt to the manufacturer

# Replacing the torch neck sensor

## Preparation

- 1 Depressurise the compressed air line of the torch neck changeover station and make sure that this compressed air line remains depressurised for the duration of the work on the device
- 2 Disconnect the compressed air line from compressed air connection "A" on the torch neck changeover station



**CAUTION!** Risk of injury from escaping compressed air from compressed air connection "A". Compressed air emerges at up to 16 bar (232.06 psi) from compressed air connection "A" when the Unlock/Lock button is pressed. While compressed air is emerging from connection "A":

- wear ear protection
- keep the face and all other body parts away from connection "A"
- ensure that no other persons are in the vicinity of the torch neck changeover station


- 3 Press and hold the Unlock/Lock button on the torch neck changeover station until compressed air no longer emerges from compressed air connection "A" on the torch neck changeover station
  - compressed air amplifier in the torch neck changeover station discharges
- 4 De-energise the torch neck changeover station

## Safety




**CAUTION!** Risk of injury from compressed air escaping unintentionally. The torch neck changeover station must remain depressurised and de-energised until all work is completed.

## Removing the old torch neck sensor




- 1 Undo the 8 screws (1)
- 2 Remove lid (2)



- 3** Remove the cable tie (3)
- 4** Unplug the plug from the PC board according to the position of the rack holder. In this case (4)


Example:

- Torch neck rack mounted at position 2 on the rack holder - unplug the torch neck sensor at connection 'X3 sensor 2' on the PC board in the torch neck changeover station




- 5** Remove the cable tie (5)
- 6** Undo screw (6)
  - using a 4 mm Allen key
- 7** Feed the sensor cable out of the torch neck changeover station
- 8** Unscrew the torch neck sensor (7) from the torch neck rack

### Fitting the new torch neck sensor



- 1** Screw the new torch neck sensor into the torch neck rack until it reaches the dimension shown
- 2** Tighten screw (1)
  - using a 4 mm Allen key
- 3** Fix the sensor cable to the torch neck rack using the cable tie (2)




- 4** Plug in the sensor plug into the PC board according to the position of the rack holder. In this case (4)

Example:

- Torch neck rack mounted at position 2 on the rack holder - connect the plug of the torch neck sensor at connection 'X3 sensor 2' on the PC board in the torch neck changeover station

- 5** Fix sensor cable using cable tie (3) as shown



- 6** Place cover onto the torch neck changeover station and secure with 8 screws (5)

### And finally...

- 1** Connect the compressed air line to compressed air connection "A" on the torch neck changeover station
- 2** Establish the compressed air supply to compressed air connection "B" on the torch neck changeover station
- 3** Connect the power supply to the torch neck changeover station

# Disposal

---

## **Disposal**

Dispose of in accordance with the applicable national and local regulations.

# **Technical data**




# Technical data

## Torch neck changeover station

Supply voltage	+ 24 V DC
Nominal pressure	6 bar 87.02 psi
Standard I/O	Input: + 24 V DC/ max. 1.5 A
Total cycle time	25 - 30 s
Degree of protection	IP 20
EMC emission class	A
Dimensions l x w x h	477 x 759 x 785 mm 18.78 x 29.88 x 30.91 in.
Weight	60 kg 132.28 lb.

## Torch neck coupling




Weight	0.825 kg 1.819 lb.
--------	-----------------------






# Appendix

# Circuit diagram: Robacta TX W




# Circuit diagram: Accessory equipment


Option: Connection Cable for TC Cleaner with Wire Cutter - 43.0004.5262




Option: Connection Cable for Robacta Reamer V Easy & Robacta Reamer Brush with Wire Cutter - 43.0004.4257



Option: TC Cleaner - 4.075.122




Option: Torch Slide




CONNECTION TO BWSVP

Option: Cover Robacta TX - 4.100.717




CONNECTION TO BWSVP


Option: Robacta Reamer V Easy - 44.0450.1444




Option: Robacta Reamer Brush - 44.0450.1449




Option: Connection Cable for Robacta Reamer V - 43.0004.4260




Option: Robacta Reamer V - 44.0450.1304





Option: Connection Cable for Wire Cutter - 43.0004.4256



Option: Wire Cutter - 44.0450.1355



# Circuit diagram: Device communication





# Declaration of installation



## EU-EINBAUERKLÄRUNG 2011 EC DECLARATION OF INCORPORATION 2011 PROHLASENI O ZABUDOVANI NEUPLNEHO STROJNIHO ZARIZENI 2011

Wels-Thalheim, 2011-04-08

Die Firma

Manufacturer

Společnost

### FRONIUS INTERNATIONAL GMBH Güter Fronius Straße 1, A-4600 Wels-Thalheim

Hiermit erklären wir, dass folgendes Produkt:

We hereby declare that the following product:

Tímto prohlašujeme, že následující výrobek:

Standkonsole TX

Standkonsole TX

Standkonsole TX

den unten angeführten, grundlegenden Anforderungen einer „unvollständigen Maschine“ im Sinne der Maschinenrichtlinie 2006/42/EG entspricht. Das Produkt ist ausschließlich zum Einbau in eine Maschine oder unvollständige Maschine vorgesehen und entspricht daher noch nicht sämtlichen Anforderungen der Maschinenrichtlinie. Die Inbetriebnahme des Produkts ist solange untersagt, bis festgestellt wurde, dass die Maschine, in die das o. g. Produkt eingebaut wird, allen grundlegenden Anforderungen der Maschinenrichtlinie 2006/42/EG entspricht. Die speziellen technischen Unterlagen gemäß Anhang VII Teil B wurden erstellt.

conforms to the essential requirements listed below of "partly completed machinery" within the meaning of the Machinery Directive, 2006/42/EU. The product is intended exclusively for installation in machinery or partly completed machinery. It therefore does not yet fully conform to all the requirements of the Machinery Directive. It is not permitted to commission the product until it is has been established that the machinery in which the above product is installed conforms to all the requirements of the Machinery Directive, 2006/42/EU. The special technical documents according to Annex VII Part B have been created.

odpovídá níže uvedeným základním požadavkům „neúplného strojního zařízení“ ve smyslu směrnice o strojních zařízeních 2006/42/ES. Výrobek je určen výhradně k vestavbě do strojního zařízení nebo neúplného strojního zařízení, a proto ještě nesplňuje veškeré požadavky směrnice o strojních zařízeních. Výrobek nesmí být uveden do provozu, dokud nebude ověřeno, že strojní zařízení, do kterého má být výše uvedený produkt instalován, splňuje všechny základní požadavky směrnice o strojních zařízeních 2006/42/EG. Zvláštní technické podklady podle přílohy VII, část B byly vytvořeny.

Richtlinie 2006/42/EG  
Maschinenrichtlinie  
**Anhang I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

Directive 2006/42/EC  
Machinery Directive  
**Annex I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

Směrnice 2006/42/ES  
Směrnice pro strojní zařízení  
**Annexe I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

Dokumentationsverantwortlicher:  
(technische Dokumentation)

person responsible for documents:  
(technical documents)

Pracovník odpovědný za  
dokumentaci:  
(technická dokumentace)

Ing. Josef Feichtinger  
Güter Fronius Straße 1  
A - 4600 Wels-Thalheim

Ing. Josef Feichtinger  
Güter Fronius Straße 1  
A - 4600 Wels-Thalheim

Ing. Josef Feichtinger  
Güter Fronius Straße 1  
A - 4600 Wels-Thalheim

# 2011

ppa. Mag.Ing.H.Hackl



**DICHIARAZIONE DI INCORPORAZIONE DI QUASI-MACCHINE, 2011**  
**DECLARACION DE INCORPORACION DE UNA CUASI MAQUINA, 2011**  
**DECLARAÇÃO DE INCORPORAÇÃO DE UMA QUASE-MÁQUINA, 2011**

Wels-Thalheim, 2011-04-08

Costruttore

La empresa

A empresa

**FRONIUS INTERNATIONAL GMBH**  
Günter Fronius Straße 1, A-4600 Wels-Thalheim

Con la presente si dichiara che il seguente prodotto:

Mediante la presente declaramos que el siguiente producto:

Declaramos que o seguinte produto:

**Standkonsole TX**

**Standkonsole TX**

**Standkonsole TX**

è conforme ai requisiti fondamentali di seguito elencati relativi a una "macchina incompleta" ai sensi della Direttiva Macchine 2006/42/CE. Il prodotto è previsto esclusivamente per essere montato in una macchina o in una macchina incompleta e pertanto non è conforme a tutti i requisiti della Direttiva Macchine. La messa in funzione del prodotto è pertanto vietata fino a quando non viene determinato che la macchina in cui il prodotto summenzionato viene montato è conforme a tutti i requisiti fondamentali della Direttiva Macchine 2006/42/CE. È stato redatto il fascicolo tecnico specifico ai sensi dell'Allegato VII, parte B.

cumple los requisitos fundamentales, indicados a continuación, de una "máquina incompleta", tal y como se define en la directiva sobre máquinas 2006/42/CE. El producto está previsto exclusivamente para su montaje en una máquina o en una máquina incompleta, por lo que aún no cumple todos los requisitos de la directiva sobre máquinas. Queda prohibida la puesta en servicio del producto hasta que conste que la máquina en la que se instala el producto anteriormente indicado cumple todos los requisitos fundamentales de la directiva sobre máquinas 2006/42/CE. Se ha elaborado la documentación técnica especial según el anexo VII parte B.

corresponde aos requisitos fundamentais abaixo listados de uma "Máquina incompleta" na aceção da diretriz de máquinas 2006/42/CE. O produto destina-se apenas ao CI, conjunto de instalação, em uma máquina ou máquina incompleta e, portanto, ainda não corresponde a todos os requisitos da diretriz de máquinas. A colocação em funcionamento do produto é proibida até que seja constatado que a máquina, na qual o produto acima será instalado, corresponde a todos os requisitos fundamentais da diretriz de máquinas 2006/42/CE. O suporte técnico especial em conformidade com o anexo VII parte B foi elaborado.

Directiva 2006/42/CEE  
Direttiva Macchina  
**Allegato I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

Directiva 2006/42/CE  
Directiva sobre máquinas  
**Annexo I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

Directiva 2006/42/CE  
Directiva Máquinas  
**Anexo I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

responsabile tecnico:  
(fascicolo tecnico)

responsable técnico:  
(expediente técnico)

responsável técnico:  
(processo técnico)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

**2011**

ppa. Mag.Ing.H.Hackl





**EU-EINBAUERKLÄRUNG 2011**  
**EC DECLARATION OF INCORPORATION 2011**  
**DECLARATION D' INCORPORATION DE U.E., 2011**

Wels-Thalheim, 2011-04-08

Die Firma

Manufacturer

La compagnie

**FRONIUS INTERNATIONAL GMBH**  
Günter Fronius Straße 1, A-4600 Wels-Thalheim

Hiermit erklären wir, dass folgendes Produkt:

We hereby declare that the following product:

Nous déclarons par la présente que le produit suivant:

**Standkonsole TX**

**Standkonsole TX**

**Standkonsole TX**

den unten angeführten, grundlegenden Anforderungen einer „unvollständigen Maschine“ im Sinne der Maschinenrichtlinie 2006/42/EG entspricht. Das Produkt ist ausschließlich zum Einbau in eine Maschine oder unvollständige Maschine vorgesehen und entspricht daher noch nicht sämtlichen Anforderungen der Maschinenrichtlinie. Die Inbetriebnahme des Produkts ist solange untersagt, bis festgestellt wurde, dass die Maschine, in die das o. g. Produkt eingebaut wird, allen grundlegenden Anforderungen der Maschinenrichtlinie 2006/42/EG entspricht. Die speziellen technischen Unterlagen gemäß Anhang VII Teil B wurden erstellt.

conforms to the essential requirements listed below of "partly completed machinery" within the meaning of the Machinery Directive, 2006/42/EU. The product is intended exclusively for installation in machinery or partly completed machinery. It therefore does not yet fully conform to all the requirements of the Machinery Directive. It is not permitted to commission the product until it is has been established that the machinery in which the above product is installed conforms to all the requirements of the Machinery Directive, 2006/42/EU. The special technical documents according to Annex VII Part B have been created.

répond aux exigences essentielles indiquées ci-dessous, relatives à celles d'une « quasi-machine » au sens de la directive machines 2006/42/CE. Le produit est exclusivement prévu pour un montage dans une machine ou une quasi-machine et ne répond donc pas encore à toutes les exigences de la directive machines. La mise en service du produit est interdite jusqu'à ce qu'il soit constaté que la machine dans laquelle le produit précité a été monté, est en conformité avec toutes les exigences de la directive machines 2006/42/CE. Les documents techniques spéciaux, conformément à l'annexe VII Partie B, ont été élaborés.

Richtlinie 2006/42/EG  
Maschinenrichtlinie  
**Anhang I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

Directive 2006/42/EC  
Machinery Directive  
**Annex I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

Directive 2006/42/CE  
Directive aux machines  
**Annexe I: EN ISO 12100**  
**EN 61000-6-2**  
**EN 61000-6-4**

Dokumentationsverantwortlicher:  
(technische Dokumentation)

person responsible for documents:  
(technical documents)

responsable documentation:  
(technique documentation)

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

Ing. Josef Feichtinger  
Günter Fronius Straße 1  
A - 4600 Wels-Thalheim

**2011**

ppa. Mag.Ing.H.Hackl

Maahantuonti ja myynti:

**PRONIUS**

Pronius Oy

Keisarinviitta 20 B  
33960 Pirkkala

+358 (0)44 200 9060  
info@pronius.fi  
www.pronius.fi